


























INSTALLATION MANUAL




BK-024
1700X880X2180mm




M4×14





M4×12





M4×10





M4×14























M4×14









































Using instruction for shower room

1. open the switch,it can adjust the hot and cold water by turning into right and left,it is fine when you feel the temperature is ok.
2. Turning the adjuster ,it can control water running from the hand shower ,foot massager,sharp massager and top shower.
3. The hydraulic pressure is 0.4Mpa in every part.
4. Please turn off the power and switch off the shower room after you used it.
5. Please swab the shower room with soft cloth,it will keep new.
The front and back of shower room are high - quality tampered glass,please don't impact it.

