












INSTALLATION MANUAL

















BK-035







1500X1500X2200mm





































Using instruction for shower room


- 1, Open the switch, it can be adjusted the hot and cold water by turning into right and left side, it is fine when you feel temperature is ok.
- 2, Turning the adjuster, it can control water running from the hand shower, foot massager, sharp massager and top shower.
- 3, The hydraulic pressure is 0.4Mpa in every part.
- 4, Please turn off the power and switch of the shower room after used it.
- 5, The glass of shower room is high-quality tempered glass, please don't impact it.

Power Request




DXD HEATER

MODEL	SDP-1500 A		
VOLTAGE	220-240VAC	50/60Hz	
POWER	1.5KW	HP	2




DXD PUMP

MODEL DXD-310 A AC 220-240V 50Hz 700W CLASS B IPX5
MAX WATER TEMPERATURE 50C 15u F/450V Hmin 1m



Mround properly!
Do Not Start Pump
Without Water!



The hot and cold water pipe and connect parts should be bought by client.

