



DC305(A/G) DC306(A/G/E) DC307(A/G) DC313(A/G/E) DC313(A/G/E) DC306(A/G/E) DC307(A/G) DC313(A/G/E) DC313(A/G/E) DC306(A/G/E) DC307(A/G) DC313(A/G/E) DC313(A/G/E)

Transmitter: You can choose single channel (DC305(A/G)), five channels (DC306(A/G/E)), or ten channels (DC307(A/G) and DC313(A/G/E)). Each indicator light means one control channel. Press "channel choose" button P1 (indicator move left side) or P1+ (indicator move right side) to change the channel. On the analogy of this, loose finger when the indicator light move to suitable channel that you select effective channel. All indicator lights flash that means all channels is effective (group control state).


- Input voltage: 3V(CR2430)
Transmitting frequency: 433MHz & 868MHz & 447.7MHz
Transmitting power: 10 milliwatt
Operating temperature: -20°C ~ +55°C
Transmission distance: 200 meters open office
35 meters on two walls

Transmitter: You can choose nine channels (DC305(A/G)), fifteen channels (DC306(A/G/E)), or one number of LCD screen means one control channel. Press "channel choose" button P1 (number descending) or P1+ (number increasing) to change the channel. On the analogy of this, loose finger when the indicator light move to suitable channel that you select effective channel. If LCD screen number show 0 that means all channels is effective (group control state).


Notice: transmitter Do not exposed to moisture and strike, so as not to affect life. When you use transmitter, if found emission distance obviously short or less sensitive, please change another same new battery. Please have batteries for recycling.




Matchable R Tubular Motor Set up



Matchable DC227/DC228 Tubular Motor Set up



Matchable DC136 Tubular Motor Set up



DC305(A/G) DC306(A/G/E) DC307(A/G) DC313(A/G/E) DC313(A/G/E) DC306(A/G/E) DC307(A/G) DC313(A/G/E) DC313(A/G/E) DC306(A/G/E) DC307(A/G) DC313(A/G/E) DC313(A/G/E)

Emitter Specification

Version No.: A/05



Type Specification

Table with 3 columns and 2 rows showing emitter models and their features. Row 1: DC305(A) DC305G, DC306(A) DC306G DC306E, DC305(A/G) DC306(A/G/E) Back. Row 2: DC307(A) DC307G, DC313(A) DC313G DC313E, DC307(A/G) DC313(A/G/E) DC313(A/G/E) Back.

DC305G DC306G DC307G DC313G DC313E and DC305(A) DC306(A) DC307(A) DC313(A) have different button mark, but the function is the same.